



**TYPICAL CURB DETAIL**  
NOT TO SCALE

**NOTES:**

1. TOP OF CURB SHALL BE PITCHED FOR DRAINAGE. LEVEL EQUIPMENT BETWEEN 4x4 AND LEGS.
2. REFER TO INSTALLATION PROCEDURES.
3. PROVIDE PRESSURE TREATED FRAMING AS BRACING EVERY 16" O.C.
4. ALL LUMBER MUST BE WOLMANIZED.
5. SIZE CURB TO INCLUDE PIPE FLASHING BOX ON TOP OF CURB.

**INSTALLATION PROCEDURE FOR ROOF CURB ON AN INVERTED COAL TAR ROOF SYSTEM**

1. REMOVE BALLAST, FILTER FABRIC, & INSULATION, FOLD BACK SLIP SHEET. SAVE MATERIAL FOR REINSTALLATION LATER.
2. CUT OUT ROOF MEMBRANE, LEAVE VAPOR BARRIER AND SET CURB ON ROOF DECK.
3. FASTEN CURB TO DECK.
4. CUT MEMBRANE BACK 2" ON ALL SIDES OF CURB AND INSTALL BITUMEN DAM.
5. INSTALL 4" CANT STRIP, IF NECESSARY.
6. INSTALL 4 PLIES OF COAL TAR PITCH TYPE I AND 15# TAR SATURATED ORGANIC FELT. EXTEND EACH PLY AT LEAST 4" FARTHER ONTO EXISTING ROOF THAN THE PRECEDING PLY.
7. INSTALL S.B.S WITH GRANULAR SURFACE FLASHING INCLUDING HOT POLYESTER BACKING PLY WITH TYPE III STEEP ASPHALT. COAT WITH COAL TAR PITCH AT BOTTOM OF FLASHING.
8. REINSTALL ITEMS REMOVED IN LINE 1.
9. LINE PERIMETER OF CURB WITH 2'x2'x2" PAVERS (6,500 PSI MINIMUM)
10. INSTALL COPPER CAP.